







RADIATION DAMAGE STUDIES ON PLASTIC SCINTILLATORS USING A 137Cs GAMMA RAY SOURCE

EMRAH TIRAS

- - -

DEPARTMENT OF PHYSICS & ASTRONOMY
UNIVERSITY OF IOWA


- - -

New Perspectives, Fermilab June 13-14, 2016

OUTLINE

- 1 Introduction
- 2 Radiation Resistant Scintillators
- 3 LED Stimulated Recovery
- 4 Accelerated Beam Tests
- 5 Summary & Conclusion

Motivation for Particle Detector Development



What are we looking for?

- ✓ Compact
- ✓ High light yield
- ✓ High resolution
- ✓ Radiation resistant
- ✓ Fast
- ✓ Cost effective particle detectors.

Our goal is:

- to provide the best solution for the CMS Calorimeter Phase II Upgrade and future collider experiments.
- to find/improve the high-performance, radiation-hard: active media and readout components


For any particle experiments in general and for CMS in specific



Calorimeter Design

Calorimeters;

- stop particles to measure the energy of them $(p^{+/-}, p^{o})$
- are too large to absorb as much particle energy as possible



Radiation Resistance Key

Collision energy and luminosity (# of particles/sec.) are increasing so total radiation level is increasing.

Scintillating Materials: we look at different materials


- Polyethylene Naphthalate (PEN)
- Polyethylene Terephthalate (PET)

PEN:

- ✓ Intrinsic blue scintillation (425 nm)
- ✓ Short decay time

PET:

- ✓ A common type polymer
- ✓ Plastic bottles and as a substrate in thin film solar cells.
- ✓ Emission spectrum of PET peaks at 385 nm [Nakamura, 2013]



Readout PMT


Trigger PMT

Optical Fiber


Laser pulse

Platform

Laser








Irradiation of Scintillators


- We irradiated our samples with using ¹³⁷Cs gamma source at Iowa Rad Core
- 1 Mrad and 10 Mrad

Initial damage

Permanent damage - plateau




 Damage was calculated in terms of light yield




Summary of irradiation results

Initial damage




 PET was damaged more than PEN initially

Permanent damage



 Permanent damage was same at 10 MRad

Time for Recovery




 PEN was recovered in 5 days only and PET in 25 days – so slow

LED Stimulated Recovery


Can we stimulate the recovery of scintillators damaged from radiation?


✓ By using an array of tri-color red, blue, green (RGB) LEDs




Different Materials:


- Eljen brand EJ-260 (N) and overdoped version EJ2P.
- Lab produced plastic scintillator (SiX)






LED Stimulated Recovery







Tile	'a', Total Recovery	'c', Permanent Damage
SiX RGB	$56.3 \pm 2.4\%$	$30.7 \pm 1.6\%$
SiX dark box	$45.7 \pm 2.5\%$	$44.1 \pm 1.9\%$
EJN RGB	$24.0 \pm 2.2\%$	$6.92 \pm 0.7\%$
EJN dark box	$21.1 \pm 1.8\%$	$15.9 \pm 0.6\%$
EJ2P RGB	$26.9 \pm 3.1\%$	$15.\bar{2} \pm 0.9\%$
EJ2P dark box	$26.5 \pm 2.2\%$	$13.7 \pm 0.7\%$

- SiX showed significant effect, the sample on RGB LED recovering 10% more and faster (4.5 vs 5.5 days)
- Neither EJN and EJ2P showed significant effect.
 - 'Blue' scintillators respond to color spectrum but 'green' scintillators are affected very little.

Accelerated Beam Tests

Where?

- CERN Test Beam Area
- Fermilab Test Beam Facility

What beam?


- Shower particles: electrons, pions, etc.
- Minimum Ionizing particles: muons, protons, etc.

What materials?


- Quartz plates coated with various organic materials
 - p-Terphenyl (pTp),
 - Gallium-doped Zinc Oxide (ZnO:Ga)
 - Anthracene (An)
- PEN, PET and HEM


What geometry and readout?

- Sigma & Bar shape
- SiPM, PMT












Accelerated Beam Test Results









PET_SIGMA-SHAPE_JFWLS_WOG_Center









PET \rightarrow Light yield mean 30.92

PET is faster but emits less light. PEN is radiation resistant up to 10 Mrad and it has a significant light yield but its so slow.

Summary & Conclusion

What about a blended sample of PEN and PET?

- ➤ It was produced and tested by H. Nakamura, et al. and light yield of the blended substrate was measured 0.85 times that of PEN and much higher than that of PET.
- ➤ The blended sample is yet to be investigated for signal timing properties.

Why LED stimulates the recovery and how can they be integrated?

Progressive research is still underway




Fig. 5. Light yield distributions for PET, PEN, and the 1:1 blend of PET and PEN.

H. Nakamura et al. / Radiation Measurements 59 (2013) 172-175